



90 Monarch Road
Guelph, Ontario, N1K 1S3

Phone: 855-658-4330
Fax: 855-658-9384

www.ecologix.ca
info@ecologix.ca

Installation Instructions

TWF

Thru-wall Condensing Unit

For replacement of existing through-wall AC Units

Fitting 24" X 32" wall sleeves

R-410a refrigerant

ECOLOGIX HEATING TECHNOLOGIES INC.

REV: 3/6/2018



90 Monarch Road
Guelph, Ontario, N1K 1S3

Phone: 855-658-4330
Fax: 855-658-9384

www.ecologix.ca
info@ecologix.ca

Contents


IMPORTANT NOTES FOR THE INSTALLER	3
WIRING DIAGRAMS	4
TWF 12.....	4
TWF 18.....	4
INTRODUCTION	5
PRODUCT DESCRIPTION	5
<i>Cabinet</i>	5
<i>Coil</i>	5
<i>Motorized EC Fan</i>	5
INSTALLATION	5
<i>Inspection</i>	5
<i>Location</i>	5
<i>Operating Environment</i>	6
<i>Mounting – Wall Sleeve</i>	6
REFRIGERANT LINES – CHARGING	6
ELECTRICAL	7
<i>Low Voltage Control Wiring</i>	8
START-UP PROCEDURES	8
SERVICE AND MAINTENANCE	9
TROUBLESHOOTING	9
START UP INFORMATION AND TROUBLESHOOTING CHART	11
WARRANTY	12

IMPORTANT NOTES FOR THE INSTALLER


<input checked="" type="checkbox"/>	A Quick Check List
<input type="checkbox"/>	Is the wall sleeve installed square and caulked to the exterior wall?
<input type="checkbox"/>	Is the grille installed?
<input type="checkbox"/>	Is the base of the cabinet or sleeve sloped to the outdoors?
<input type="checkbox"/>	Are the refrigerant lines connected at the air handler and condenser?
<input type="checkbox"/>	Is the suction line insulated?
<input type="checkbox"/>	Is the disconnect properly sized and installed according to local code?
<input type="checkbox"/>	Is there an installation manual for the homeowner?
<input type="checkbox"/>	Is the low voltage wire connected between air handler and condenser?
<input type="checkbox"/>	Are the service panels closed?
<input type="checkbox"/>	Is the unit accessible? Are there clearances for service?
<input type="checkbox"/>	Has the refrigerant charge been verified by measuring sub-cooling?
<input type="checkbox"/>	Has the fan speed been set to minimize noise & match capacity?

WIRING DIAGRAMS

TWF 12



TWF 18



INTRODUCTION

TWF™ wall-sleeve condenser units are designed for use with Ecologix air handlers. This unit is dimensioned to fit a standard 32" tall by 24" wide wall sleeve. The unit is designed to exceed the efficiency of the replaced equipment by a

substantial margin. The system is equipment with a large oversized condenser coil and variable speed EC motorized fan to maximize efficiency and minimize operating noise.

PRODUCT DESCRIPTION

Cabinet

All cabinets have a tough, durable low maintenance G90 galvanized finish.

Cabinet dimensions. Refer to product specifications and installation requirements for more details.

Replacement grilles are available as a special order to compliment the building exterior.

Coil

All coils and internal piping conform to ASTM B68 or ASTM B88 standards. High-density aluminum fins provide maximum heat transfer for small coil surface.

Motorized EC Fan

The motorized EC fan can be manually set to optimize capacity and lower fan speed to a minimum for extra quiet operation.

INSTALLATION

WARNING !

Installation should only be performed by qualified personnel. In addition to this manual, all local codes shall be followed.

Improper installation may void all warranties.

Inspection

Carefully uncrate the equipment. Ensure that the rated voltage and capacity on the nameplate matches the requirement for the installation. If there is damage to the machine, a claim must be made to your carrier immediately. Shipping damage is

the responsibility of the purchaser to file all necessary documents with their carrier. Remove any shipping materials.

Location

Consideration must be given to location. The unit must be mounted in an area with adequate clearance and access for

servicing. Consideration must also be given to noise and vibration that is normal for operation of this unit. Additional isolation may be required in occupant sensitive locations. If the original installation had noise issues, this unit can relieve but not eliminate those issues.

Confirm there is at least six feet clearance in front of the grille outdoors for proper air circulation and heat dissipation.

Operating Environment

Do not install in a corrosive environment containing chlorine, fluorine, solvents or other corrosive chemicals. Do not install in any atmosphere containing explosive or flammable vapours.

Internal controls should not be exposed to temperatures above 105°F/41°C.

If the unit is to be operated at temperatures below 50°F/10°C, a cold weather kit must be installed.

Mounting – Wall Sleeve

Inspect the existing wall sleeve prior to installing unit. The wall sleeve should be square and installed flush to the outdoor finished wall surface. The wall sleeve can be fastened through the inside face of the sides to the building framing with #10 pan head screws. Do not screw through the base of the wall sleeve. The base of the wall sleeve should have the required slope built in to match the slope of the Wall sleeve condenser to provide adequate drainage. There is no need to slope the condenser outward for drainage. The entire base of the wall sleeve should be properly supported. Inspect flashing and seal on outside edge of wall sleeve to ensure a watertight finish. Make sure drip edge at bottom extends beyond wall finish.

REFRIGERANT LINES – CHARGING

WARNING !

Refrigerant lines are to be connected by qualified personnel only. Improper installation can result in injury or improper operation of the equipment.

Slide the condenser into the wall sleeve. Remove the service panel. The TWF comes with the refrigerant lines stubbed out the top left side of the cabinet when facing the access panel. The service valves are located in the interior of the cabinet accessible through the access panel. Connect refrigerant lines on top of the cabinet using appropriate air conditioning brazing methods and materials. Protect pipe seals where pipes enter the

condenser cabinet. Refer to the specification table for line sizes. The compressor is pre-charged with refrigerant for a 10 foot line-set. For other line-set lengths, add or subtract 0.4 oz of refrigerant per foot of line. Where the evaporator and TWF unit are separated by more than 20 feet vertically, loop the refrigerant to form a trap every 16 feet. The evaporator height above or below the compressor shall not exceed 40 feet vertically.

For the TWF18 and 24 models the equivalent length from the condenser to the evaporator shall not exceed 140 feet, including elbows and fittings. For the TWF12 compressor, the line lengths shall not exceed 40 feet. And the evaporator height above or below the TWF12 compressor shall not exceed 15 feet vertically.

Insulate the vapour (suction) line with suitable pipe insulation.

The correct refrigerant charge is listed on the rating plate for each unit. Information for charging is contained on the inside panel of the unit

Test ports are available so the system can be run with gauges hooked up and

the doors on.

All Ecologix matched coils use a TX valve for refrigerant expansion. The correct charge is verified by measuring the sub-cooling at the condenser discharge.

Once system is operating, check that the correct charge is installed by measuring temperature and pressure of liquid line from the condenser. Sub cooling should be 10F +5F /- 3F. If it is outside of this range, add or remove refrigerant from the liquid side as required.

Model	Liquid Line	Suction Line (Vapor)		
		Up to 40 feet	40-80 feet	80 - 140 feet
TWF12	1/4 in.	1/2 in.	NA	NA
TW18	3/8 in.	5/8 in.	5/8 in.	5/8 in.
TW24	3/8 in.	5/8 in.	5/8 in.	3/4 in.

ADJUSTMENT FOR CAPACITY FOR LONG LINE SETS

Nominal capacity (Btuh)	Vapor line diameter (in.)	Equivalent Line Length (FT)				
		50	75	100	125	140
12,000	1/2	NA	NA	NA	NA	NA
18,000	5/8	0.99	0.97	0.96	0.95	0.95
24,000	5/8	1.00	0.99	0.99	0.98	0.97

Equivalent lengths of fittings (Add to measured length)

Type of elbow fitting	Inside Diameter (in.)		
	5/8	3/4	7/8
90° short radius	1.4	1.7	2
90° long radius	1.3	1.5	1.7
45°	0.6	0.7	0.8

ELECTRICAL

WARNING !

Make sure unit is properly grounded. Locate condensing unit on a separate electric circuit. Provide a line of site disconnect according to local code requirements.

The wiring diagram is located on the service door. A copy is provided in this document for reference only. Nameplate data is located on the side of the unit. Ampacity is also shown in the specification table. If there is a difference in ampacity and circuit size between the rating plate and this document, the rating plate shall be followed.

All condensers operate on 230VAC/1ph/60hz line voltage. All control circuits are 24 VAC.

Use copper conductors only. Connect power wires to terminal lugs in the control panel. Protect and seal wires where they enter the condenser cabinet.

Low Voltage Control Wiring

Connect low voltage control wire, such as thermostat wire, between the low voltage terminals of the middle panel and the terminals of the air handler. Typical air handler terminal labels would be AC or Y & C. Protect and seal wires where they enter the condenser cabinet.

START-UP PROCEDURES

1. Verify power is connected to the condensing unit and the air handler.
2. Verify control wire is connected from the air handler to the condenser unit. Verify that the thermostat is installed.
3. Verify that refrigerant lines are connected between the air handler and condenser unit, evacuated and properly charged.
4. Install the service panel of the condenser unit. Install all panels and filters at the air handler.
5. Turn on the power to the air handler and condenser unit. Set the room thermostat for cooling to energize the fan and condenser. Note: some thermostats and air handlers have a five minute lock-out delay.
6. Use refrigerant gauges to check and adjust superheat. Take air temperature measurement before and after coil and adjust fan speed to a setting that is acceptable for sound and achieves a temperature rise less than 30F.

SERVICE AND MAINTENANCE

WARNING !

Service should only be provided by qualified personnel. Disconnect electrical supply before opening service panels.

Wiring

Examine wires for signs of pinching, fraying or charring. Replace as necessary.

Coil

Examine the condenser coil for lint, debris or damage. Wash or vacuum if necessary.

Fan and motor

Check fan for dust once a year. The fan is accessible and removable through the panel. If dirty, vacuum to remove dust. Keeping the fan blades clean will reduce noise and improve the capacity and efficiency of the cooling system.

TROUBLESHOOTING

WARNING !

Service should only be performed by qualified personnel. Take proper care to disconnect voltage supply. Use caution when working near charged capacitors.

Symptom	Cause	Check
Fan and compressor will not operate	<ol style="list-style-type: none"> 1. Power off 2. Improperly wired 3. Loose connections 4. 24vac supply 5. Thermostat 6. Firestat/Freezestat 	<ol style="list-style-type: none"> 1. Check main fuse/circuit breaker and remote disconnect. Measure power and control voltages at condenser. 2. Check power and control wiring. Refer to wiring diagram. 3. Check wiring. 4. Measure voltage and check ampacity (should be at least 40VA, replace transformer if faulty or under-sized). 5. Thermostat or air handler may have a delay of up to five minutes. Check thermostat settings. Disconnect thermostat and apply 24vac directly from air handler. If it operates, fault is at thermostat or a.h. control. 6. Determine cause of trip. Repair/reset/replace

		Firestat/freezestat if necessary.
Fan operates, compressor does not	Safety lock-out	<ol style="list-style-type: none"> 1. Reset thermostat 2. Push HP switch if manual reset.
Compressor hums, won't start	<ol style="list-style-type: none"> 1. Low voltage or wrong voltage 2. Capacitor problem 	<ol style="list-style-type: none"> 1. Check wiring and voltage at unit, check wire size, check for loose wires. 2. Test compressor capacitor, replace if necessary
Fan starts but cuts out	<ol style="list-style-type: none"> 1. Incorrect or low voltage 2. Capacitor problem 3. Doesn't turn freely 4. Seized 5. High internal amperage 	<ol style="list-style-type: none"> 1. Check wiring and voltage at unit, check wire size, check for loose wires. 2. Test fan capacitor, replace if necessary 3. Oil motor, check bearings, replace fan motor if necessary. 4. Replace fan motor 5. Change to lower fan speed
High suction pressure	<ol style="list-style-type: none"> 1. Excessive evap. Air 2. Excessive load 3. High latent heat 	<ol style="list-style-type: none"> 1. Confirm correct amount of evap. Air, adjust air handler air flow. 2. Estimate space cooling load and compare to unit capacity. Replace with larger cooling unit if necessary. 3. Estimate space cooling latent load and compare to unit latent capacity.
High discharge pressure	<ol style="list-style-type: none"> 1. Insufficient air over condenser. 2. Plugged or restricted air over condenser coil 	<ol style="list-style-type: none"> 1. Adjust condenser fan speed. 2. Wash or vacuum condenser coil.
Fan is loud	<ol style="list-style-type: none"> 1. Fan speed not set 2. Coil plugged 	<ol style="list-style-type: none"> 1. Adjust fan speed using speed control in electric panel behind access door. 2. Inspect coil and wash if necessary.

If you require diagnostic assistance, complete the Troubleshooting chart and send to your distributor.

WARRANTY

This product is warranted by Ecologix Heating Technologies Inc to be free from defects in materials and workmanship that affect product performance under normal use and maintenance within the applicable periods specified below. Replacements furnished will carry only the un-expired portion of the original warranty.

Two-Year Parts

Ecologix Heating Technologies Inc will provide replacement parts for ANY part that fail within two years of purchase, subject to the **terms** below.

Five-Year Parts

Ecologix Heating Technologies Inc will provide replacement parts for compressor, refrigerant coil, cabinetry and piping that fail within five years of purchase, subject to the **terms** below.

Terms

- ❖ Reasonable proof of original purchase date must be provided in order to establish the effective date of the warranty, failing which, the effective date will be based on the date of manufacture plus thirty days.
The warranty does not cover failure or damages caused by:
 - improper installation or operation
 - accident, abuse or alteration
 - operation of device at temperatures or pressures outside of the rated capacities
 - corrosive operating environment
 - equipment moved from original installation location
- ❖ Replacements furnished under this warranty will be F.O.B. Ecologix Heating Technologies Inc product distribution points in the United States and Canada. They will be invoiced at regular prices. The account will be credited the full amount when the defective part is received by Ecologix, examined and approved as a valid warranty.
- ❖ Warranty applies to the original purchaser, but may be transferred to another owner provided the equipment is not moved from the original installation site.
- ❖ This warranty does not apply to labour, freight or any other cost associated with the service repair or operation of the product.
- ❖ Ecologix shall not be liable for any direct, special, incidental or consequential damages caused by the use, misuse, or inability to use this product.
- ❖ Ecologix is under no legal obligations to rectify, including but not limited to, lost profits, downtime, good will, damages to, or replacement of equipment and property
- ❖ Purchaser assumes all risk and liability of loss, damage or injury to purchaser and purchaser's property and to others and their property arising out of the use, misuse or inability to use this product.